

INSTALLATION INSTRUCTIONS INSTRUCTIONS D'INSTALLATION

IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. **DANGER**- Risk of shock- Disconnect power before installation.
DANGER – *Risque de choc – Couper l'alimentation avant l'installation.*
2. Must be installed in accordance with the NEC or your local electrical code. If you are not familiar with these codes and requirements, consult a qualified electrician.
Ce produit doit être installé conformément à NEC ou votre code électrique local. Si vous n'êtes pas familier avec ces codes et ces exigences, veuillez contacter un électricien qualifié.
3. Indoor use only.
Pour usage interieur seulement.



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

SMARTCAST® TOUCHSCREEN CONTROL KIT INCLUDES:


- (1)- Tablet
- (1)- 90 degree USB-C to USB-C cable
- (1) - Wall-mount kit
- (1)- Recessed wall box
- (1)- Battery modulator

REQUIRED BY CUSTOMER:

- 120V outlet
- Single gang wall plate



Installation of the provided recessed wall box, battery modulator, and wall-mount kit are required to complete the installation of the SmartCast® Touchscreen Control. See **Figure 1**.



INSTALLATION

STEP 1:

Install the Recessed Wall Box in a landscape orientation per the included installation instructions.

NOTE: Do not remove the audio/video/data knockouts from the Recessed Wall Box.

STEP 2:

Install the Wall-Mount Kit over the Recessed Wall Box per the included installation instructions.

STEP 3:

Plug the Tablet adapter into the outlet.

STEP 4:

Connect the Battery Modulator to the Tablet adapter and the Tablet. See **Figure 2**.

STEP 5:

After performing OneButton™ Setup on the lighting network and configuring the SmartCast® Wireless Gateway with WiFi, power on and setup the SmartCast® Touchscreen by following the on-screen instructions. For setup and troubleshooting information please refer to the resources available at - <https://www.creelighting.com/touchscreen-help>.