





**Continuous Row Through Wiring Kits (optional field-installed accessory)**

**Ordering Information**

Example: LS4TWK


Qty.
<b>Through Wiring Kits</b>
<p><b>LS4TWK</b> Includes (3) #12AWG 54" (1372mm) Wires for Line (black), Neutral (white), Ground (green), (2) #18AWG 54" (1372mm) Wires for 0-10V Dimming (purple, gray) and (10) Wire Nuts. - Optional accessory for use when luminaire is not ordered with factory installed TW option - Order one per luminaire - Does not power luminaires w/EB14 option. Additional unswitched (i.e. continuous power) dedicated feeds (by others) must be supplied to EB14</p>
<p><b>LS8TWK</b> Includes (3) #12AWG 102" (2591mm) Wires for Line (black), Neutral (white), Ground (green), (2) #18AWG 102" (2591mm) Wires for 0-10V Dimming (purple, gray) and (10) Wire Nuts. - Optional accessory for use when luminaire is not ordered with factory installed TW option - Order one per luminaire - Does not power luminaires w/EB14 option. Additional unswitched (i.e. continuous power) dedicated feeds (by others) must be supplied to EB14</p>

**Top Housing Aligner Accessory for Continuous Rows (optional field-installed accessory)**

**Ordering Information**

Example: LS-RJ


Qty.
<b>Joint Aligner</b>
<p><b>LS-RJ</b> Top housing aligner for continuous rows. - Order one less than the number of luminaires in your run</p>



**Installation Configurations**



Notes:  
PF = Power Feed & Cable Support  
NF = Non-Power Feed Cable Support



Notes:  
PF = Power Feed & Cable Support  
NF = Non-Power Feed Cable Support  
LS-RJ = Top Housing Aligner Accessory for Continuous Rows

PRELIMINARY